

O & M

Beha SKO 300 T

Shoe dryer

BEHA



Description of the heater SKO 300 T

Beha shoe dryer SKO 300 T is for wall mounting. It has 60cm long tubes. The air is drawn in at the front and are led through the heating element down into the tubes. The shoe dryer can be used with timers from 30-180 min. or without timer.

The packaging is recyclable and should be disposed of in paper containers for cardboard.

Electrical connection and use

Before connecting, please ensure that the voltage is 230V AC 50Hz. The heater should be connected to the electrical socket in the room where it is intended to be used. Do not connect the heater with an extension cable as this may cause a fire hazard.

Care and Maintenance

Turned the switch off. Remove the cord from the socket by gripping the plug and gently pull it out of the wall socket. Make sure the heater is cooled down before cleaning. Clean the outside with a damp cloth. Never use abrasive cleaners or submerse the heater in water or other liquids.

Vacuum back and frontside twice a year.

Other information

Defective heater must be delivered to a collection point for electrical waste. The heater must not be repaired, dismantled, or modified.

Dimension

Name	Effect	Height mm	Length mm	Depth mm	Item no.	El.no.	Nobb no.	GTIN
SKO 300 T	300W	230	230	100	317610	54 283 85	25396797	7026573176105