O & M PGV and LGV Wi-Fi Gen 2 heaters with glass front



RFHA

Description of Beha Wi-Fi Gen 2 heaters

Convector heaters with electronic thermostat intended for basic heating. If the temperature changes, it will be shown with a projector on the floor for 10 seconds. Beha PGV and LGV Gen 2 heaters have built in Wi-Fi with Bluetooth® technology for connection to the Beha app. The heaters can be controlled remotely with internet and a smartphone.

The heater can also be used manually, with the temperature dial on the heater.

After power outage the heater will use the last set temperature/program. If the heater uses a program from the app, it continues with the program and set temperatures.

The heaters can be turned OFF and ON in manual program. The Beha app is designed to be able to control heaters in several locations.

The heaters have an open window detection. If the temperature in the room exceeds 15 degrees, and the temperature drops more than 5 °C within 40 seconds the open window function is activated. The function is active for a maximum of 15 minutes.

The packaging is recyclable and should be disposed of in paper containers for cardboard.

Electrical connection and use

Before connecting, please ensure that the voltage is 230V AC 50Hz. The heater should be connected to the electrical socket in the room where it is intended to be used. Do not connect the heater with an extension cable as this may cause a fire hazard.

Care and maintenance

Remove the cord from the socket by gripping the plug and gently pulling it out of the wall socket. Make sure the heater is cooled down before cleaning. Clean the outside with a damp cloth. Never use abrasive cleaners or submerse the heater into water or other liquids.

Vacuum behind and underneath the heater, twice a year. Before vacuuming released the wall bracket on top of the heater. On PGV heater the two arms on the wall bracket are mounted in the T slot in the back plate. On LGV heater the lower part of the wall bracket, will hold the heater when vacuuming.

Other information

Defective heater must be delivered to a collection point for electrical waste. The heater must not be repaired, dismantled, or modified.

Name	PGV 4 Wi-Fi Gen 2	PGV 6 Wi-Fi Gen 2	PGV 8 Wi-Fi Gen 2	PGV 10 Wi-Fi Gen 2	PGV 12 Wi-Fi Gen 2	LGV 7 Wi-Fi Gen 2	LGV 10 Wi-Fi Gen 2
ltem no.	810650	810651	810652	810653	810654	810655	810656
Effect (W)	400	600	800	1000	1250	750	1000