

# INSTRUCTION MANUAL

# BEHA

## Hekla VT 2000

### Heater



**PLEASE READ AND SAVE THESE INSTRUCTION MANUAL TO ENSURE THE SAFE AND EFFECTIVE USE OF THE APPLIANCE.**

**This product is only suitable for well insulated spaces or occasional use.**

## DESCRIPTION OF THE SYMBOLS

Before any use, refer to the corresponding section in this user manual.



In accordance with European directives applicable to this product



Class II symbol: this appliance is designed with double



The crossed-out wheeled bin symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling in accordance with local environmental regulations for waste disposal. By separating a marked item from household waste, you will help reduce the volume of waste sent to incinerators or land-fill and minimize any potential negative impact on human health and the environment

## IMPORTANT SAFETY INSTRUCTIONS

Warning: To avoid the risk of electrical shock, always make sure the products is unplugged from the electrical outlet before relocating, servicing, or cleaning it.

1. This product is intended for indoor, non-commercial, household use for temporarily heating residential rooms. Do not use the product for any other purpose.
2. Do not leave the product unattended while it is in use. Always unplug the product from the electrical outlet when it is not use.
3. Keep the product out of the reach of children and pets. This product is not intended for use by children.
4. Place the product on a flat, steady, stable, heat-resistant surface.
5. This product has arcing or sparking parts inside. Do not use it in areas when gasoline, paint, or flammable liquids are used or stored, as there may be a risk of fire or explosion.
6. Use the product in a well-ventilated area. This heater is hot when in use. To avoid burns, do not let bare skin touch a hot surface. If provided, use handle when moving this heater. Keep combustible materials, such as furniture, pillows, bedding, paper, clothes, and curtains at least 3 feet (0.9 meters) from all sides of the heater.
7. Use this heater only as described in this manual. Any other use is not recommended by the manufacturer. As it may cause fire, electric shock,

or personal injury.

8. Do not insert or allow other objects to enter any ventilation of or exhausted opening as this may cause an electric shock, fire or product damage.

9. To prevent a possible fire, do not block air intake or exhaust in any manner. Do not use on soft surface, such as a bed, where air outlet may become blocked.

10. Wipe the air openings clean if they become clogged.

11. Do not use this product to dry or heater clothing, shoes, pipes or any other items.



12. **WARNING:** In order to avoid overheating, do not cover the heater.

13. The heater can be used in bathrooms, rooms used to dry clothes, or other humid or wet environments, but on the condition that you follow international rules for IP21 and Zone 3 classification (e.g. min 60 cm horizontally from the edge of the washbasin)

14. Never place the heater where it may fall into a bathtub or other water container.

15. Plug the product into a standard AC 220-240V electrical outlet.

16. To disconnect the product, turn the switch off first, and then remove the plug from the electrical outlet. Pull directly on the plug; do not pull on the power cord.

17. Do not put any stress on the power cord where it connects to the product, as the power cord could fray and break.

18. Do not plug or unplug the product from the electrical outlet with a wet hand.

19. Keep the power cord and product away from heated surfaces

20. Do not operate the heater with a damaged cord or plug, once malfunctions occurred, or has been dropped or damaged in any manner. Please seek help from professional service facility for examination, electrical or mechanical adjustment, or repair.

21. **CAUTION:** This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

22. Children should be supervised to ensure that they do not play with the appliance.

23. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.


24. Children of less than 3 years should be kept away unless continuously supervised.

25. Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.

**CAUTION — Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.**



### List of main parts


1. Operating panel
2. Display
3. Air outlet Grill




### Operation panel



1. Temperature/Timer up
2. Temperature/Timer down
3.  ON/OFF switch
4.  Mode button:  
To choose Regular Fan/Warm Fan/Hot Fan  
Hold on 5s to set the timer
5. Turn button: Oscillation



**Remote control indication.**





6. Temperature up/Timer up
7. To choose Regular Fan/Warm Fan/Hot Fan,
8. To set timer
9. Temperature down/Timer down
10. 3 color indicator light on/off
11. On/off heater
12. Oscillation


**Technical Specifications:**


<b>Model Number</b>	Beha Hekla VT 2000
<b>Rating Voltage</b>	220-240 V ~ 50-60 Hz
<b>Power</b>	2000 W
<b>Protection Class</b>	Class II
<b>Waterproof</b>	IP21 (Zone 3)



## Operation on heater:



1. Plug the power cord into a standard 230V AC electrical outlet.
2. Turn on the main switch at back side of heater.


3. Press “” button to start the heater and press  button to

change the mode, each pressing on the  button, the heater will have one dot (fan only mode), two dots (1 setting mode) or 3 dots (2 setting mode) showing on display.

4. Press “” button, the heater will turn automatically with an angle about 75°.

5. Press “” or “” button, setting the temperature you need (16-37°C).


6. Hold on “” button for 5 seconds, display shows timer, press “”


or “” button to set the timer you need to auto power off the heater (up to 9 hours), the display will shine 3 times to finish the setting.



7. The product will keep running a few seconds after turning off.
8. The display showing will turn to low light automatically after 60 seconds.




## Operation on remote control:


1. Plug the power cord into a standard 230V AC electrical outlet.
2. Turn on the main switch at back side of heater.

3. Press “” button to start the heater and press **MODE** button to change the mode, each pressing on the **MODE** button, the heater will have one dots (fan only mode), two dots (1 setting mode) or 3 dots (2 setting mode) showing on display.

4. Press  button, the heater will turn automatically with an angle about 75°.

5. Press “” or “” button, setting the temperature you need (16-37°C).

6. Press  button and press “” or “” button to set the timer you need to auto power off the heater(up to 9 hours), the display will shinning 3 times to finish the setting.

7. Press  button, to control the 3 color indicator light on and off.

## MAINTENANCE AND STORING

Always disconnect the appliance and let it cool down completely before carrying out any maintenance. Use a vacuum cleaner to remove dust on inlet and outlet surfaces. Clean the outside of the unit with a damp cloth and then dry it with a dry cloth. Never immerse the unit in water, nor let water drip into the unit. Always disconnect the appliance, let it completely cool and clean it before storing. If you do not use the device for a long period, put back the unit and the instruction manual to the original carton and store in a dry and ventilated place. Do not place any heavy items on top of carton during storing as this may damage the appliance.

## Environmental considerations

Please note that this product is marked with the following symbol:



This means that this product must not be disposed of with normal household waste, as waste electrical and electronic equipment should be disposed of separately. According to the WEEE Directive, each member state must ensure the proper collection, recycling, handling and recycling of electrical and electronic waste. Private households in the EU can deliver used equipment to certain recycling stations free of charge. In some member states, used appliances can be returned to the retailer where they were purchased, provided that new products are purchased. Contact your dealer, distributor or government authorities for further information on what to do with waste electrical and electronic equipment.

## Warranty: (Applies to Norway)

A warranty is provided for 12 months against manufacturing defects. In addition, the provisions of the Sale of Goods Act on the right of complaint apply. For inquiries regarding complaints or warranty, a purchase receipt or similar must be presented as documentation of the date of purchase. Special rules apply to business purchases. However, it is assumed that the appliance is taken to the retailer where the appliance was purchased. The appliance must always be packed securely at the time of shipment. Damage caused by improper use, wear and tear, moisture damage, overvoltage, or intervention by unqualified personnel is not covered by the warranty. Such damage will only be repaired for a fee. For more info, please visit our website [www.beha.no](http://www.beha.no), or call our free support phone 820 500 50 (12.00 – 14.00 every weekday) if you want advice and tips.

### Importer:

Beha Target AS, Evjeløkka 3, 1661 Rolvsøy, Norway, [post@beha.no](mailto:post@beha.no)



## Product specification:

Model identifier(s): Beha Hekla VT 2000					
Item	Symbol	Value	unit	Item	unit
Heat output				<b>Type of heat input, for electric storage local space heaters only (select one)</b>	
Nominal heat output	P <sub>nom</sub>	2.0	kW	manual heat charge control, with integrated thermostat	[no]
Minimum heat output (indicative)	P <sub>min</sub>	1.0	kW	manual heat charge control with room and/or outdoor temperature feedback	[no]
Maximum continuous heat output	P <sub>max,c</sub>	2.0	kW	electronic heat charge control with room and/or outdoor temperature feedback	[no]
<b>Auxiliary electricity consumption</b>				fan assisted heat output	[no]
At nominal heat output	e <sub>lmax</sub>	0.000	kW	<b>Type of heat output/room temperature control (select one)</b>	
At minimum heat output	e <sub>lmin</sub>	0.000	kW	single stage heat output and no room temperature control	[no]
In standby mode	e <sub>lSB</sub>	0.001	kW	Two or more manual stages, no room temperature control	[no]
				with mechanic thermostat room temperature control	[no]
				with electronic room temperature control	[yes]
				electronic room temperature control plus day timer	[no]
				electronic room temperature control plus week timer	[no]
				<b>Other control options (multiple selections possible)</b>	
				room temperature control, with presence detection	[no]
				room temperature control, with open window detection	[no]
				with distance control option	[no]
				with adaptive start control	[no]
				with working time limitation	[no]
				with black bulb sensor	[no]